


ASSEMBLY INSTRUCTIONS: SEAT 2 FOOT LENGTH 187001 and 187002

1. Unpack and lay out pieces to assemble. Verify that the parts, quantity, and dimensions match those on the enclosed bill of material.
2. Begin by placing two bull nose boards down on the ground or work area with curved side facing away from each other. Place two rectangular boards between the two bull nose boards. Begin with one bull nose board and use other boards as working shims.
3. Place one weldment with plate having 8 drilled holes down against the boards and locate plate at a distance of 4 inches from plate side edge to end of bull nose and at a distance of 2 1/8 inches from plate end edge to flat side of bull nose. Use a hand square to line up plate on the bull nose surface. See diagram 1.
4. Drill 5/32 diameter pilot hole (two places) into the board and install two 1/4 x 2 screws into the board. (use end 2 holes in metal plate of weldment as a drill guide)
5. Place the other weldment with plate having 8 drilled holes down against the board and locate at a distance of 16 1/2 inches from plate side edge to same end of bull nose used in step 4 and at a distance of 2 1/8 inches from plate end edge to flat side of bull nose. See diagram 1.
6. Drill 5/32 diameter pilot hole (two places) into the board and install two 1/4 x 2 screws into the board. (use end 2 holes in metal plate of weldment as a drill guide)
7. Locate one rectangular board at a distance of 4 inches from plate side edge to end of board and at a distance of 1/2 inch from bull nose flat edge. (Ref. 1/2 inch gap between sides of boards at each end.) See diagram 1.
8. Drill 5/32 diameter pilot hole (four places) into the board and install four 1/4 x 2 screws into the board. (use second line of 2 holes in metal plate of weldment as a drill guide)
9. Locate second rectangular board at a distance of 4 inches from plate side edge to end of board and at a distance of 1/2 inch from previous board. (Ref. 1/2 inch gap between sides of rectangular boards at each end.)
10. Drill 5/32 diameter pilot hole (four places) into the board and install four 1/4 x 2 screws into the board. (use third line of 2 holes in metal plate of weldment as a drill guide)
11. Locate second bull nose board at a distance of 4 inches from plate side edge to end of board and at a distance of 1/2 inch from previous board at both ends. (Ref. 1/2 inch gap between sides of boards at each end.)
12. Drill 5/32 diameter pilot hole (four places) into the board and install four 1/4 x 2 screws into the board. (use fourth line of 2 holes in metal plate of weldment as a drill guide)
13. Check square ness of seat before tightening screws.

DIAGRAM 1: SEAT 2 FOOT LENGTH PORTABLE 187001 SHOWN



Turn to sheet two with diagram 2 for mounting instructions


ASSEMBLY AND MOUNTING INSTRUCTIONS – FORESITE DESIGNS®
2 FOOT SEAT, PARK SCAPES™ DESIGN 187001 AND 187002

PAGE 2


MOUNTING INSTRUCTIONS: SEAT 2 FOOT LENGTH 187001, 187002

1. Surface mount seat 187001 mounts with ½ inch anchors into concrete surface at dimensions as shown on diagram 2.
2. Embedded mount seat 187002 mounts by setting in filled holes at dimensions as shown on diagram 2.

DIAGRAM 2: SEAT 2 FOOT LENGTH, SHOWN ARE
SURFACE 187001 CONCRETE ANCHORS 4 PLACES



EMBEDDED 187002 HOLES 2 PLACES



BILL OF MATERIAL – 187001		
PART #	DESCRIPTION	QTY
72-100120	WELDMENT, SEAT, SURFACE MT., WITHOUT ARMS	2
	2 X 4 X 24” BULL-NOSE PLASTIC LUMBER	2
	2 X 4 X 24” SQUARE CORNER PLASTIC LUMBER	2
71-0018	FASTENER KIT INCLUDES:	1

BILL OF MATERIAL – 187002		
PART #	DESCRIPTION	QTY
72-100115	WELDMENT, SEAT, EMBEDDED, WITHOUT ARMS	2
	2 X 4 X 24” BULL-NOSE PLASTIC LUMBER	2
	2 X 4 X 24” SQUARE CORNER PLASTIC LUMBER	2
71-0018	FASTENER KIT INCLUDES:	1